

**ICP PANEL-TEC
MICROGATE**

**BACNET TO
SIEMENS SED2 DRIVE
APPLICATION**

**INSTALLATION
AND
OPERATION
GUIDE**

REVISION HISTORY

| Revision | Date | Author | Comments |
|----------|--------------|--------------|---|
| 000 | 19 May 2008 | David Walker | Initial release. |
| 001 | 16 July 2008 | David Walker | Added AI4, AI5, BI9 & BI10 Added support for 76,800bps Changed configuration to support 22-bit device instance number |

TABLE OF CONTENTS

| | |
|--|----|
| Introduction | 4 |
| Part Numbers | 4 |
| Table 1 - Part Numbers | 4 |
| Hardware | 5 |
| Power Supply..... | 5 |
| Programming Switch | 5 |
| Serial Port Pinouts | 5 |
| Table 2 - Serial Port Pinouts | 5 |
| BACnet Network Cable | 6 |
| Figure 1 - BACnet Network Cable | 6 |
| USS SED2 Drive Cable | 6 |
| Figure 2 - USS Drive Cable..... | 6 |
| Table 3 – SED2 Cable Connections | 6 |
| LED Indicators | 7 |
| Table 4 – MicroGate General Status LED (STAT) | 7 |
| Table 5 - Network Communications Activity LED (NET)..... | 7 |
| Table 6 – USS-SED2 Communications Activity LED (LCL) | 7 |
| MicroGate Configuration..... | 8 |
| Configuration Cable | 8 |
| Figure 3 - Configuration Cable..... | 8 |
| Default Configuration..... | 8 |
| Table 7 - Configuration Options | 8 |
| Changing the Configuration | 9 |
| Figure 4 - MicroGate Configuration Display..... | 9 |
| SED2 Drive Setup | 10 |
| SED2 Drive Parameter Configuration | 10 |
| Table 8 – SED2 Parameter Configuration | 10 |
| Watchdog Timer Setup | 10 |
| Verifying the Installation..... | 11 |
| BACnet Objects..... | 12 |
| Table 9 - Binary Input Objects Supported | 12 |
| Table 10 - Binary Value Objects Supported | 12 |
| Table 11 - Analog Value Objects Supported | 13 |
| Table 12 - Analog Input Objects Supported | 14 |
| Table 13 - Multistate Value Objects Supported..... | 14 |

INTRODUCTION

The BACnet to USS version of the MicroGate connects one SED2 drive to a BACnet MS/TP Network. A pre-defined set of BACnet objects are provided that allow access to the most common drive parameters, monitor values, setpoint values, and control points for the SED2 drive.

Part Numbers

The MicroGate product is sold with several different applications. To ensure that the correct version of the MicroGate is procured, please include the correct part number when ordering. Part numbers for the BACnet to USS MicroGate and the optional power supply are as follows:

Table 1 - Part Numbers

| Part Number | Description |
|--------------------|--------------------------|
| 5005-201-102 | MicroGate BACnet to SED2 |
| 4000-0204 | MicroGate Power Supply |

HARDWARE

Power Supply

The MicroGate requires a regulated 5V DC power source, capable of supplying a minimum of 250mA. Power may be supplied to the MicroGate by either connecting the MicroGate Power Supply to the Input Power jack on the side of the unit, or by providing regulated 5V DC power to pin 9 of the Local serial port.

Programming Switch

The Programming Switch on the MicroGate should always be in the RUN position for normal operations and configuration. The PRG position is used strictly for loading firmware at the factory.

Serial Port Pinouts

The MicroGate comes with two serial ports. The pinouts for the serial ports are shown in the table below.

The Local port is for connection to a local device (in this case, an SED2 Drive), and supports both RS232 and RS485 (2-wire) communications. The Local port is also used for configuration and programming of the MicroGate.

The Network port is for connection to a network (in this case, a BACnet network), and supports RS485 (2-wire) and RS422 (4-wire) communications.

Table 2 - Serial Port Pinouts

| Local: DB9-Female | | | Network: DB9-Male | | |
|-------------------|-------|------------------|-------------------|----------|--------------------------------|
| Pin | Label | Description | Pin | Label | Description |
| 1 | 485+ | RS485 D+ | 1 | 485+ | RS485 D+/RS422 RX+ |
| 2 | TXD | RS232 TxD | 2 | 485- | RS485 D-/RS422 RX- |
| 3 | RXD | RS232 RxD | 3 | 422+ | RS422 TX+ |
| 4 | DTR | RS232 DTR | 4 | 422- | RS422 TX- |
| 5 | GND | Reference Ground | 5 | GND | Reference Ground |
| 6 | 485- | RS485 D- | 6 | 485TERM+ | RS485 D+/RS422 RX+ Termination |
| 7 | RTS | RS232 RTS | 7 | 485TERM- | RS485 D-/RS422 RX- Termination |
| 8 | CTS | RS232 CTS | 8 | 422TERM+ | RS422 TX+ Termination |
| 9 | VCC | +5VDC Input | 9 | 422TERM- | RS422 TX- Termination |

BACNet Network Cable

The user must provide a cable to connect the NETWORK port on the MicroGate to a BACNet network. An example of the connections of such a cable is shown below. Because the BACnet connection type may vary among different installations, no connector type is indicated – the user must specify the correct connector and pinout for this end of the cable.




Figure 1 - BACnet Network Cable

USS SED2 Drive Cable

The user must provide a cable to connect the LOCAL port on the MicroGate to the SED2 drive. The cable should end in stripped wires to facilitate connection to the MM40 drive terminals shown in the table below. SED2 drive power should be off while connecting the wires to the drive terminals.




Figure 2 - USS Drive Cable

Table 3 – SED2 Cable Connections

| Signal | Connection |
|--------|-------------------|
| 485+ | SED2 Terminal #29 |
| 458- | SED2 Terminal #30 |

LED Indicators

There are a total of 3 Bi-color LED indicators on the MicroGate. The NET LED displays communications activity on the Network (BACnet) port. The STAT LED displays the overall status of the MicroGate. The LCL LED displays communications activity on the Local (USS-SED2) port. During normal operations, the NET and LCL LEDs will quickly alternate red and green flashes, making it look almost amber. This is normal.

Table 4 – MicroGate General Status LED (STAT)

| For this state: | LED is: | To indicate: |
|------------------------|---|---|
| No Power | Off | There is no power applied to the device. |
| Run Mode | Flashing Green (250ms On, 250ms Off) | The MicroGate is operating normally in RUN Mode. |
| Configuration Mode | Flashing Green (1.5 sec On, 1.5 sec Off) | The MicroGate is in Configuration Mode. |
| Fatal Error | Flashing Yellow (250ms On, 250ms Off) | The MicroGate has experienced a fatal error, and has halted communications. |

Table 5 - Network Communications Activity LED (NET)

| For this state: | LED is: | To indicate: |
|------------------------|----------------|---|
| Receive Data | Red | The MicroGate is receiving data from the BACnet Network. |
| Transmit Data | Green | The MicroGate is transmitting data onto the BACnet Network. |

Table 6 – USS-SED2 Communications Activity LED (LCL)

| For this state: | LED is: | To indicate: |
|------------------------|----------------|---|
| Receive Data | Red | The MicroGate is receiving data from the SED2 drive. |
| Transmit Data | Green | The MicroGate is transmitting data to the SED2 drive. |

MICROGATE CONFIGURATION

Configuration Cable

The local port on the MicroGate includes RS232 signals for use in configuration, as shown in the pinout and cable diagram below. A standard straight-through DB9-F to DB9-M cable connects the MicroGate to a serial port on a PC during configuration.




Figure 3 - Configuration Cable

Default Configuration

The BACnet protocol on the Network Port of the MicroGate is configurable to make it easy to add it to an existing BACnet network. The configuration parameters that may be changed are shown in the following table:

Table 7 - Configuration Options

| Parameter | Options | Default |
|-----------------|---|--------------|
| Data Link | MS/TP Master MS/TP Slave | MS/TP Master |
| MAC Address | 0-127 (Master) 0-255 (Slave) | 10 |
| Device Instance | 0-4194303 | 1 |
| Baud Rate | 9600 bps 19200 bps 38400 bps 76800 bps Autobaud | 19200 bps |

The MicroGate always acts as a Server on the BACnet network. However, the data link layer may be configured as BACnet MS/TP Master (token passing) or BACnet MS/TP Slave (non token passing).

If Autobaud is selected for the Baud Rate, the MicroGate will attempt to detect the baud rate of the network at startup. Once it has detected a valid baud rate to use, it will continue to use that baud rate. If the baud rate of the network changes after a valid baud rate has been detected, the MicroGate will not detect the new baud rate unless it is powered off and back on.

Changing the Configuration

The configuration stored in the MicroGate may be changed from the default configuration by entering Configuration Mode.

1. Attach a configuration cable between the Local port on the MicroGate and a serial port on a PC.
2. Start a terminal program, such as Hyper Terminal, on the PC, and connect using the following settings:
 - o Baud = 9600 bps
 - o Data bits = 8
 - o Parity = None
 - o Stop Bits = 1
 - o Flow Control = None
3. With the Programming Switch set to “RUN”, apply power to the MicroGate, and send a carriage return (press the **Enter** key) within 5 seconds of startup.

Once the MicroGate is in Configuration Mode, it will send its current configuration information to the terminal program, as follows:




Figure 4 - MicroGate Configuration Display

Use the **up** and **down** arrows on your keyboard to navigate to the field you want to change, then use the **left** and **right** arrows to change the value in that field. When you are finished, navigate to “Save Configuration” and press the **Enter** key to save the configuration information to the MicroGate.

Once the configuration has been saved, remove power from the MicroGate and remove the configuration cable.

SED2 DRIVE SETUP

SED2 Drive Parameter Configuration

The Siemens SED2 drive must be configured before the MicroGate will communicate with the drive. The MicroGate communicates with the SED2 drive using the USS protocol, with the following configuration:

- 19200 baud
- 8 data bits
- even parity
- 1 stop bit
- drive id 0

To setup the SED2 drive for communications with a MicroGate, the drive parameters in the following table must be configured with the values shown via the SED2 keypad.

Table 8 – SED2 Parameter Configuration

| SED2 Parameter | Function | Set Value |
|----------------|---------------------------|---|
| P0003 | User Access Level | 3 (Expert Setting) |
| P0700[0] | Command Source | 5 if Starting/Stopping Drive from BACnet Otherwise: Do Not Change |
| P1000[0] | Frequency Setpoint Source | 5 if Setting the Frequency from BACnet Otherwise: Do Not Change |
| P2009[0] | USS Normalization | 0 (Disabled) |
| P2010[0] | USS Baud Rate | 7 (19.2K baud) |
| P2011[0] | USS Address | 0 |
| P2014[0] | USS telegram off time | 0 to Disable the USS “watchdog” timer, or > 0 to enable the USS “watchdog” timer (NOTE: values less than 100ms are not recommended) |

Watchdog Timer Setup

The SED2 has a timeout function for the USS port, which is controlled by Parameter 2014, “USS telegram off time”. Once the MicroGate has established communications with an SED2 drive with the watchdog function enabled, the watchdog timer is activated. If communications are subsequently lost for the specified length of time, the SED2 will automatically generate a F0072 fault. Setting Parameter 2014 to a value of 0 disables the watchdog timer function. Setting Parameter 2014 to a non-zero value enables the watchdog timer function with the specified time. Avoid setting this value too low, as that could result in false fault indications.

Verifying the Installation

After all necessary connections have been made, power up the SED2 drive and the MicroGate, and wait approximately 5 seconds. If the MicroGate has been installed correctly, the STAT led will be flashing green, and the LCL led will be alternating so fast between red and green that it will appear to be glowing amber.

If the MicroGate is set up as an MS/TP Master, and it is connected to a BACnet network, the NET led will be alternating between red and green. If the MicroGate is set up as an MS/TP Slave, the NET led will be flickering red (it will only flash green when it responds to a request from a master).

To verify that the MicroGate and drive are set up correctly, send the following Write Property requests to the network port of the MicroGate:

- CMD SRC (MV 0) → 5 (USS on COM Link)
- SP SRC 1 (MV 1) → 5 (USS on COM Link)
- FREQ SP (AV 23) → 50.0 (%)
- RUN ENA CMD (BV 11) → 1 (ENABLE)
- RUN CMD 3 (BV 10) → 1 (ON)
- RUN CMD 2 (BV 9) → 1 (ON)
- RUN CMD 1 (BV 8) → 1 (ON)

At this point, if everything else is set up correctly, the drive should start running. The drive frequency may be changed at any time during this process by writing to the FREQ SP again.

BACNET OBJECTS

The following tables contain the list of all BACnet objects available on the MicroGate.

Table 9 - Binary Input Objects Supported

| Instance | Object Name | Description | ACTIVE Text | Inactive Text | Present Value Access Type | Mapped to |
|----------|-------------|-----------------------------------|-------------|---------------|---------------------------|-----------|
| BI 0 | DO 1 ACT | Actual Value of Digital Output #1 | ON | OFF | R | r0747:0 |
| BI 1 | DO 2 ACT | Actual Value of Digital Output #2 | ON | OFF | R | r0747:1 |
| BI 3 | DI 1 ACT | Actual Value of Digital Input #1 | ON | OFF | R | r0722:0 |
| BI 4 | DI 2 ACT | Actual Value of Digital Input #2 | ON | OFF | R | r0722:1 |
| BI 5 | DI 3 ACT | Actual Value of Digital Input #3 | ON | OFF | R | r0722:2 |
| BI 6 | DI 4 ACT | Actual Value of Digital Input #4 | ON | OFF | R | r0722:3 |
| BI 7 | DI 5 ACT | Actual Value of Digital Input #5 | ON | OFF | R | r0722:4 |
| BI 8 | DI 6 ACT | Actual Value of Digital Input #6 | ON | OFF | R | r0722:5 |
| BI 9 | DI 7 ACT | Actual Value of Digital Input #7 | ON | OFF | R | r0722:6 |
| BI 10 | DI 8 ACT | Actual Value of Digital Input #8 | ON | OFF | R | r0722:7 |

Table 10 - Binary Value Objects Supported

| Instance | Object Name | Description | Active Text | Inactive Text | Present Value Access Type | Mapped to |
|----------|--------------|---|-------------|---------------|---------------------------|-----------|
| BV 0 | STOP/RUN ACT | Indicates whether inverter is running or stopped, regardless of control source | STOP | RUN | R | ZSW:2 |
| BV 1 | FWD/REV ACT | Indicates whether the inverter is running in forward or reverse | FWD | REV | R | ZSW:14 |
| BV 2 | RUN ENA ACT | Indicates whether the inverter is enabled | ENABLE | DISABLE | R | ZSW:0 |
| BV 3 | RDY TO RUN | Indicates whether the inverter is ready to run | YES | NO | R | ZSW:1 |
| BV 4 | AT MAX FREQ | Indicates whether the maximum frequency has been reached | YES | NO | R | ZSW:10 |
| BV 5 | AT SETPOINT | Indicates whether there is no deviation between the setpoint and the actual value | YES | NO | R | ZSW:8 |
| BV 6 | FAULT ACT | Indicates whether there is an active fault in the inverter | FAULT | OK | R | ZSW:3 |
| BV 7 | WARN ACT | Indicates whether there is an active warning in the inverter | WARN | OK | R | ZSW:7 |
| BV 8 | RUN CMD 1 | 1 = ok to run (edge controlled), 0 = shutdown via ramp | ON | OFF | C | STW:0 |
| BV 9 | RUN CMD 2 | 1 = ok to run, 0 = coast to stop | ON | OFF | C | STW:1 |
| BV 10 | RUN CMD 3 | 1 = ok to run, 0 = fast stop | ON | OFF | C | STW:2 |
| BV 11 | RUN ENA CMD | Enable the inverter to run | ENABLE | DISABLE | C | STW:3 |
| BV 12 | FWD/REV CMD | Run in forward or reverse | REV | FWD | C | STW:11 |
| BV 13 | FAULT ACK | Acknowledge a fault | ACK | NO ACK | W | STW:7 |
| BV 14 | ENABLE PID | Enable PID Controller | ENABLE | DISABLE | W | P2200 |
| BV 15 | CDS | Command Data Set Bit 0 (local/remote) | YES | NO | C | STW:15 |
| BV 16 | DO 1 CMD | Commanded Value of Digital Output #1 | ON | OFF | W | P0731 |
| BV 17 | DO 2 CMD | Commanded Value of Digital Output #2 | ON | OFF | W | P0732 |
| BV 30 | HAND/AUTO | Hand/Auto function | HAND | AUTO | W | P0718 |

Table 11 - Analog Value Objects Supported

| Instance | Object Name | Description | Units | Present Value Access Type | Mapped to |
|----------|--------------|--|----------------|---------------------------|---------------------------|
| AV 0 | OUTPUT SPEED | Indicates actual filtered rotor speed | RPM | R | r0022 |
| AV 1 | OUTPUT FREQ | Indicates actual filtered output frequency | Hertz | R | r0024 |
| AV 2 | DC BUS VOLT | Indicates the actual filtered DC-link voltage | Volts | R | r0026 |
| AV 3 | OUTPUT VOLT | Indicates the actual filtered output voltage | Volts | R | r0025 |
| AV 4 | CURRENT | Indicates the actual filtered output current | Amps | R | r0027 |
| AV 5 | TORQUE | Indicates the actual filtered torque | Newton Meters | R | r0031 |
| AV 6 | POWER ACT | Indicates the actual filtered power | Kilowatts | R | r0032 |
| AV 8 | MOTOR TEMP | Indicates the measured temperature of the motor | °C | R | r0035 |
| AV 9 | KWH | Indicates the electrical energy used by the inverter | Kilowatt Hours | R | r0039 |
| AV 10 | PID SP ACT | Indicates the actual setpoint value of the motor potentiometer (PID) | Percent | R | r2250 |
| AV 11 | PID OUTPUT | Indicates the actual PID output | Percent | R | r2294 |
| AV 13 | FREQ SP ACT | Indicates the actual frequency setpoint of the inverter | Hertz | R | r0020 |
| AV 14 | FREQ ACT | Indicates the actual frequency of the inverter | Percent | R | HIW (0-4000h = 0-100%) |
| AV 15 | INV FW VER | Indicates the version of the firmware in the inverter | -- | R | r0018 |
| AV 16 | INV MODEL | Indicates the power stack code of the inverter | -- | R | r0200 |
| AV 17 | RATED POWER | Indicates the rated power of the inverter | Kilowatts | R | r0206 |
| AV 18 | LAST FLT | Indicates the most recent fault in the fault log | -- | R | r0947 |
| AV 19 | PREV FLT 1 | Indicates a previous fault in the fault log | -- | R | r0947 |
| AV 20 | PREV FLT 2 | Indicates a previous fault in the fault log | -- | R | r0947 |
| AV 21 | PREV FLT 3 | Indicates a previous fault in the fault log | -- | R | r0947 |
| AV 22 | LAST WARN | Indicates the most recent warning in the warning log | -- | R | r2110 |
| AV 23 | FREQ SP | The setpoint frequency of the inverter, as a percentage of the reference frequency | Percent | C | HSW (0-4000h = 0-100%) |
| AV 24 | FREQ REF | The reference frequency for the inverter | Hz | W | P2000 |
| AV 25 | PID SP REF | Setpoint for the motor potentiometer (PID) | Percent | W | P2240 |
| AV 26 | CUR LIM | Motor overload current limit, relative to rated motor current | Percent | W | P0640 |
| AV 27 | ACCEL TIME | The ramp up time of the inverter | Seconds | W | P1120 |
| AV 28 | DECEL TIME | The ramp down time of the inverter | Seconds | W | P1121 |
| AV 29 | PID UP LMT | The upper limit for PID controller output | Percent | W | P2291 |
| AV 30 | PID LO LMT | The lower limit for PID controller output | Percent | W | P2292 |
| AV 31 | P GAIN | The proportional gain for the PID controller | -- | W | P2280 |
| AV 32 | I GAIN | The integral time constant for the PID controller | Seconds | W | P2285 |
| AV 33 | D GAIN | The derivative time for the PID controller | Seconds | W | P2274 |
| AV 34 | PID FB GAIN | The gain applied to PID feedback | Percent | W | P2269 |
| AV 35 | PID FILTER | The time constant for the PID feedback filter | Seconds | W | P2265 |

Table 12 - Analog Input Objects Supported

| Instance | Object Name | Description | Units | Present Value Access Type | Mapped to |
|----------|-------------|--|---------|---------------------------|-----------|
| AI 0 | AO 1 ACT | Indicates actual value of Analog Output #1 after filtering and scaling | -- | R | r0774[0] |
| AI 1 | AO 2 ACT | Indicates actual value of Analog Output #2 after filtering and scaling | -- | R | r0774[1] |
| AI 2 | AI 1 ACT | Indicates actual value of Analog Input #1 after scaling | Percent | R | r0754[0] |
| AI 3 | AI 2 ACT | Indicates actual value of Analog Input #2 after scaling | Percent | R | r0754[1] |
| AI 4 | AI 1 RAW | Indicates actual value of Analog Input #1 before scaling | -- | R | r0752[0] |
| AI 5 | AI 2 RAW | Indicates actual value of Analog Input #2 before scaling | -- | R | r0752[1] |

Table 13 - Multistate Value Objects Supported

| Instance | Object Name | Description | Number of States | States | Present Value Access Type | Mapped to |
|----------|-------------|--|------------------|---|---------------------------|-----------------------|
| MV 0 | CMD SRC | Selection of the command source for the inverter | 7 | 1: BOP (keypad) 2: terminal 3: <unused> 4: USS on BOP link 5: USS on COM link 6: CB on COM link 7: factory default | W | P0700[0] ¹ |
| MV 1 | SP SRC 1 | Selection of the main frequency setpoint for the inverter | 8 | 1: MOP setpoint 2: analog setpoint 3: fixed frequency 4: USS on BOP link 5: USS on COM link 6: CB on COM link 7: analog setpoint 2 8: none | W | P1000[0] ² |
| MV 2 | SP SRC 2 | Selection of an additional frequency setpoint for the inverter | 8 | 1: MOP setpoint 2: analog setpoint 3: fixed frequency 4: USS on BOP link 5: USS on COM link 6: CB on COM link 7: analog setpoint 2 8: none | W | P1000[0] ² |

¹Changing the Present Value of this object will cause several internal parameters in the inverter to be changed.

²Commanding either MV1 or MV2 will cause P1000 to be written to the inverter with a combined value.

In the above tables, the Present Value Access Type indicates whether the present value of an object is read-only (R), writable (W) or commandable (C). Commandable objects use a priority array.

If the MicroGate fails to read a parameter from the SED2 drive for some reason, any object(s) associated with that parameter are marked as Out Of Service until the parameter is successfully read from the drive.

If the MicroGate loses communications with the SED2 drive altogether, all objects are marked as Out Of Service until communications can be reestablished and a new value is read from the drive for that object.

It is possible for certain parameters in the SED2 drive to be assigned a value via the drive keypad interface inconsistent with the values in the above tables. For example, DO 1 CMD and DO 2 CMD may be assigned values other than 0 or 1 (when the states of the associated digital outputs are to be driven by other parameters rather than directly). In such a case, the object will be marked as Unreliable until such time as the value of the parameter in the SED2 drive again corresponds to a value consistent with the object type.